

XRiso Fail

If the equipment **is not** surge-protected remove or repair equipment.

If the equipment **is surge-protected**, repeat the test by holding down the relevant Class or Cord button for approximately 5 seconds until you hear a beep.

A small triangular symbol with an exclamation mark will briefly flash at the bottom of the screen.

Release the button and the Riso test will be done at 250 volts d.c. as shown at the bottom of the screen.

The Riso test will then revert to 500 volts d.c. for the next test.

Remove or repair equipment if it still fails.